

How to find the ATM Interface MAC Address on Comtrend Routers

Comtrend AR-5071T

- Add one to the MAC on the Router

Comtrend AR-5072T

- Add one to the MAC on the Router

Comtrend AR-5381u

- Add two to the MAC on the Router

Comtrend AR-5319

- Add three to the MAC on the Router

Comtrend CT-5374

- Add two to the MAC on the Router

Comtrend VR-3060

- Add three to the MAC on the Router

NOTE: Examples below for counting in Hexadecimal

Example 1

d8:b6:b7:4f:5c:38 + 1
= d8:b6:b7:4f:5c:39 + 1
= d8:b6:b7:4f:5c:3a

Example 2

d8:b6:b7:4f:5c:3f + 1
= d8:b6:b6:4f:5c:40

Example 3

d8:b6:b7:4f:5c:ff + 1
= d8:b6:b7:4f:5d:00